

# **Guide for Root Pass Welding of Pipe Without Backing**



**American Welding Society**



**AWS D10.11M/D10.11:2007  
An American National Standard**

**Approved by the  
American National Standards Institute  
October 13, 2006**

# **Guide for Root Pass Welding of Pipe Without Backing**

**3rd Edition**

**Supersedes AWS D10.11-87**

Prepared by the  
American Welding Society (AWS) D10 Committee on Piping and Tubing

Under the Direction of the  
AWS Technical Activities Committee

Approved by the  
AWS Board of Directors

## **Abstract**

This standard presents guidelines for welding the root pass of metal pipe butt joints with an open root or a consumable insert. Joint designs, assembly, consumable insert configurations, base metals, filler metals, and purging are discussed. Applicable arc welding processes and techniques are described.



**American Welding Society**

550 N.W. LeJeune Road, Miami, FL 33126

# Table of Contents

|                                                                                            | Page No. |
|--------------------------------------------------------------------------------------------|----------|
| <i>Personnel</i> .....                                                                     | v        |
| <i>Foreword</i> .....                                                                      | vii      |
| <i>List of Figures</i> .....                                                               | xi       |
| <b>1. Scope</b> .....                                                                      | 1        |
| 1.1 Introduction.....                                                                      | 1        |
| 1.2 Units of Measure.....                                                                  | 1        |
| <b>2. Normative References</b> .....                                                       | 1        |
| <b>3. Terms and Definitions</b> .....                                                      | 2        |
| <b>4. Preparations for Welding</b> .....                                                   | 2        |
| 4.1 Cleanliness.....                                                                       | 2        |
| 4.2 Purging.....                                                                           | 3        |
| 4.3 Purge Gas Containment.....                                                             | 3        |
| <b>5. Purging Prior to Welding</b> .....                                                   | 4        |
| 5.1 Step 1.....                                                                            | 4        |
| 5.2 Step 2.....                                                                            | 5        |
| 5.3 Purge Time Estimates.....                                                              | 5        |
| 5.4 Recommended Residual Oxygen Levels.....                                                | 5        |
| <b>6. Purging During Welding</b> .....                                                     | 7        |
| 6.1 Flow Rate Reduction.....                                                               | 7        |
| 6.2 Flow Rates for Open-Root Welds and for Joints with Consumable Inserts.....             | 7        |
| 6.3 Purge Maintenance for Subsequent Weld Layers.....                                      | 7        |
| <b>7. Tack Welding</b> .....                                                               | 7        |
| 7.1 Preparation and Spacing.....                                                           | 7        |
| 7.2 Inspection, Removal of Discrepancies, and Cleaning.....                                | 7        |
| <b>8. Welding Using GTAW Without Consumable Inserts</b> .....                              | 7        |
| 8.1 General.....                                                                           | 7        |
| 8.2 Tungsten Electrode Type and Configuration.....                                         | 7        |
| 8.3 Joint Design.....                                                                      | 8        |
| 8.4 Purge Containment.....                                                                 | 8        |
| 8.5 Arc Initiation.....                                                                    | 8        |
| 8.6 Welding Technique—Open Root Groove.....                                                | 8        |
| 8.7 Welding Technique—Groove with Zero Root Opening.....                                   | 10       |
| 8.8 Welding Pipe in Various Positions.....                                                 | 10       |
| 8.9 Stop and Start Areas.....                                                              | 10       |
| <b>9. Welding Using GTAW with Consumable Inserts</b> .....                                 | 12       |
| 9.1 Description and Specifications of Consumable Inserts.....                              | 12       |
| 9.2 Welding Techniques for Consumable Inserts.....                                         | 13       |
| 9.3 Pipe Axis Horizontal.....                                                              | 13       |
| <b>10. GTAW of Stainless Steels with Flux Cored Filler Metals and Backing Fluxes</b> ..... | 13       |
| 10.1 Flux Cored Filler Metals.....                                                         | 13       |

|                                                                                   |           |
|-----------------------------------------------------------------------------------|-----------|
| 10.2 Backing Fluxes .....                                                         | 13        |
| 10.3 Limitations .....                                                            | 13        |
| <b>11. Welding Carbon and Low Alloy Steels with SMAW and GMAW .....</b>           | <b>13</b> |
| 11.1 Introduction.....                                                            | 13        |
| 11.2 Shielded Metal Arc Welding (SMAW) with Cellulosic Covered Electrodes .....   | 13        |
| 11.3 Low Hydrogen (Basic) SMAW for Open Gap Root Pass Welding .....               | 14        |
| 11.4 Shielded Metal Arc Welding (SMAW) with Rutile Covered Electrodes.....        | 16        |
| 11.5 Gas Metal Arc Welding (GMAW) .....                                           | 16        |
| <b>12. Intermediate Weld Layers.....</b>                                          | <b>16</b> |
| 12.1 Inspection and Purging .....                                                 | 16        |
| 12.2 Processes and Limitations.....                                               | 16        |
| <b>13. Welding of Aluminum Alloys .....</b>                                       | <b>17</b> |
| 13.1 Characteristics of Aluminum that Affect Welding Techniques .....             | 17        |
| 13.2 Welding Techniques .....                                                     | 17        |
| <b>14. Welding Equipment .....</b>                                                | <b>17</b> |
| 14.1 GTAW Torches .....                                                           | 17        |
| 14.2 Gas Nozzles .....                                                            | 17        |
| 14.3 Gas Lenses .....                                                             | 17        |
| 14.4 Power Supplies .....                                                         | 17        |
| 14.5 Machine and Automatic Welding Equipment .....                                | 18        |
| Annex A (Informative)—Guidelines for the Preparation of Technical Inquiries ..... | 21        |
| List of AWS Documents on Piping and Tubing.....                                   | 23        |

## List of Figures

| <b>Figure</b> |                                                                                                                                                       | <b>Page No.</b> |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| 1             | Purging Fixtures .....                                                                                                                                | 4               |
| 2             | Preweld Purge Time for 300 mm [12 in] Length of Pipe of Various Sizes .....                                                                           | 6               |
| 3             | Typical Open Root Joint Design.....                                                                                                                   | 8               |
| 4             | Angular Relations Between Pipe, Torch, and Filler Metal for Open Root Welding .....                                                                   | 9               |
| 5             | Feeding Filler Metal Through the Root Opening in Limited Access Areas .....                                                                           | 10              |
| 6             | Groove Design, Dimensions, and Tolerances for Use with Consumable Inserts .....                                                                       | 11              |
| 7             | Assembly Tolerances for Welding Pipe, Using Five Classes of Consumable Inserts .....                                                                  | 12              |
| 8             | Steps for Root Pass Welding with Classes 1, 2, 3, and 5 Consumable Inserts .....                                                                      | 14              |
| 9             | Steps for Root Pass Welding with Class 4 Consumable Inserts .....                                                                                     | 15              |
| 10            | Eccentric Positioning of Classes 3 and 5 Consumable Inserts in 5G Position (Axis Horizontal,<br>Pipe Not Rotated During Welding) to Prevent Sag ..... | 16              |
| 11            | Joint Design for Aluminum Pipe .....                                                                                                                  | 17              |

# Guide for Root Pass Welding of Pipe Without Backing

## 1. Scope

This document describes how to make root weld passes on circumferential pipe groove welds using open root joints with filler metal additions, tightly-fitted joints without the addition of filler metal, and joints with consumable inserts. Joint designs, fitting techniques, consumable insert configurations, filler and base metal combinations, purging, and welding processes are discussed. This publication does not address joints made using backing rings and techniques applicable to mechanized orbital welding.

Safety and health issues and concerns are beyond the scope of this standard, and therefore are not fully addressed herein. Safety and health information is available from other sources, including, but not limited to, ANSI Z49.1, *Safety in Welding, Cutting, and Allied Processes*, and applicable federal and state regulations. See Clauses 2 and 15 and Annex A for additional safety and health references.

**1.1 Introduction.** When the pipe system designer has determined that the use of backing rings is unacceptable due to service conditions and that complete joint penetration, including a continuous root side surface, is needed, butt joints may be made from one side using the groove designs and techniques described in this document. Although gas tungsten arc welding (GTAW) is most commonly used for precise control in root pass welding, shielded metal arc welding (SMAW) and gas metal arc welding (GMAW) are also widely used.

**1.2 Units of Measure.** This standard makes use of both the International System of Units (SI) and U.S. Customary Units. The latter are shown within brackets [ ] or in appropriate columns in tables and figures. The measurements may not be exact equivalents; therefore, each system must be used independently.

To identify nominal pipe sizes in both SI and U.S. Customary Units, the following designations are used:

1. DN (Diameter Nominal) is the SI designation.
2. NPS (Nominal Pipe Size) is the U.S. Customary designation.

## 2. Normative References

The following standards contain provisions which, through reference in this text, constitute provisions of this AWS standard. For undated references, the latest edition of the referenced standard shall apply. For dated references, subsequent amendments to, or revisions of, any of these publications do not apply.

AWS Documents:<sup>1</sup>

1. AWS A3.0, *Standard Welding Terms and Definitions*
2. AWS A5.1/A5.1M, *Specification for Carbon Steel Electrodes for Shielded Metal Arc Welding*
3. AWS A5.5/A5.5M, *Specification for Low Alloy Steel Electrodes for Shielded Metal Arc Welding*
4. AWS A5.12/A5.12M, *Specification for Tungsten and Tungsten Alloy Electrodes for Arc Welding and Cutting*
5. AWS A5.30/A5.30M, *Specification for Consumable Inserts*
6. AWS A5.32/A5.32M, *Specification for Welding Shielding Gases*
7. AWS C5.5/C5.5M, *Recommended Practices for Gas Tungsten Arc Welding*
8. AWS C5.10/C5.10M, *Recommended Practices for Shielding Gases for Welding and Plasma Arc Cutting*
9. AWS D10.4, *Recommended Practices for Welding Austenitic Chromium-Nickel Stainless Steel Piping and Tubing*

<sup>1</sup>AWS standards are published by the American Welding Society, 550 N.W. LeJeune Road, Miami, FL 33126.